
#### Materials & Tests Unit



### NCDOT

## ABC MATERIALS SCHOOL

2010 version

# SOILS LABORATORY TECHNICAL TRAINER STAFF

- David Dunn
   Divisions 1, 2, and 4
- Kevin Blalock Divisions 3, 6, and 8
- Johnny Gilliam Divisions 5 and 7
- Scotty Jarman Divisions 9, 10, and 12
- J.J. Myers Divisions 11, 13, and 14

# MANUFACTURING AGGREGATE

WHY DO WE HAVE SPECIFICATIONS?

• ABC IS A MANUFACTURED PRODUCT AND DUE TO ITS EXPOSURE TO WATER AND DYNAMIC LOADING, SPECIFICATION REQUIREMENTS WERE ESTABLISHED TO ENSURE THE PRODUCT WOULD HAVE DESIRABLE PERFORMANCE

• FOR "THIN" ASPHALT PAVEMENT (FLEXIBLE PAVEMENT), THE ABC IS THE PRIMARY LOAD-BEARING ELEMENT

#### IT BEGINS WITH THE DESIGN PROCESS...

PAVEMENT DESIGN ENGINEERS USE LAYER COEFFICIENTS FOR THE DIFFERENT TYPES OF MATERIALS THAT MAKE UP A PAVEMENT STRUCTURE

FOR EXAMPLE...

(BASE LAYER) B 25.0 ASPH	IALT0.30 (PER INCH)
ABC	0.14 (PER INCH)
CTBC	0.23 (PER INCH)
LIME STAB. SUBGRADE	0.13 (PER INCH)


SINCE THE LAYER COEFFICIENT OF ABC IS BASED ON MATERIAL MEETING CERTAIN GRADATION REQUIREMENTS...




IT IS IMPORTANT TO MONITOR GRADATION
OF THE MATERIAL BEING PLACED TO ENSURE
IT WILL PERFORM AS INTENDED

# GRADATION REQUIREMENTS ARE DESIGNED TO CREATE A WELL-GRADED BLEND OF AGGREGATE WHICH...

- INCREASES NUMBER OF FICTION POINTS
- INCREASES THE INTERLOCKING BETWEEN PARTICLES
- DECREASES VOIDS



# TRANSMISSION OF FORCE THROUGH THE AGGREGATE



• STRENGTH IS CREATED FROM FICTION AND INTERLOCKING BETWEEN ADJACENT PARTICLES

#### DUE TO THE ABC BEING EXPOSED TO WATER, LIQUID LIMIT AND PLASTICITY INDEX ARE ALSO CRITICAL COMPONENTS


• LIQUID LIMIT (L.L.)

THE WATER CONTENT AS DETERMINED BY THE STANDARD LIQUID LIMIT TEST, AT WHICH A SOIL PASSES FROM A PLASTIC TO A LIQUID STATE

- PLASTIC LIMIT (P.L.)

  THE LOWEST WATER CONTENT, AS DETERMINED
  BY THE STANDARD PLASTIC LIMIT TEST, AT WHICH
  A SOIL REMAINS PLASTIC
- PLASTICITY INDEX (P.I.) P.I. = L.L. - P.L.






THE LIQUID LIMIT AND PLASTIC LIMIT ARE DETERMINED ON THE MATERIAL PASSING THE # 40 SIEVE

A HIGH LIQUID LIMIT INDICATES A HIGH CLAY CONTENT AND LOW LOAD-CARRYING CAPACITY

LOAD-CARRYING CAPACITY OF A SOIL INCREASES
RAPIDLY BELOW THE PLASTIC LIMIT AND DECREASES
RAPIDLY ABOVE THE PLASTIC LIMIT

TABLE 1010-1 AGGREGATE BASE COURSE GRADATION ACCEPTANCE RANGE


Column A	Column B	Column C	Column D	Column E
Column	% Passing	% Passing	Range	Column E
1 1/2''	70 I assing	70 I assing	Range	
	100	98 - 100	3	1
(37.5 mm)				
1"	75 - 97	72 - 100	15	1
(25.0 mm)	13-71	72 - 100	15	1
1/2**	55 - 80	51 - 83	20	1
(12.5 mm)				
# 4	35 - 55	35 - 60	18	3
(4.75 mm)				
# 10	25 - 45	20 - 50	18	2
(2.00 mm)				
# 40	14 - 30	10 - 34	14	3
(0.425 mm)				
# 200	4 - 12	3 - 13	7	5
(0.075  mm)				
Material Passing No. 10 Sieve (Soil Mortar)				
# 40	10 01	26.06	25	2
(0.425 mm)	40-84	36-86	35	<b>L</b>
# 200	11 25	10.26	20	2
(0.075 mm)	11-35	10-36	20	2
Material Passing No. 40 Sieve				
L. L.	0-30	0-30	-	-
P. I.	0-6	0-6	-	-















# QC/QA PROGRAM

## **PURPOSE**

- NCDOT IN A JOINT VENTURE WITH THE AGGREGATE INDUSTRY CREATED THE QC/QA PROGRAM
- STONE PRODUCERS PERFORM QUALITY CONTROL (QC) SAMPLING AND TESTING
- NCDOT PERFORMS QUALITY
  ASSURANCE (QA) TESTING AND
  MONITORS THE PRODUCER'S QC
  PROGRAM

- UNDER THE QC/QA PROGRAM, THE PRODUCER PULLS A QC SAMPLE AT THE QUARRY AND PROCESSES IT
- GRADATION RESULTS ARE CHECKED AGAINST SPECS (TABLE 1010-1) FOR ACCEPTENCE
- RESIDENT ENGINEERS ARE
  SCHEDULED TO RECEIVE RESULTS
  WITHIN 72 HOURS (REFER TO QC/QA
  PROGRAM AND TESTING MANUALS
  FOR FURTHER DETAILS)

# AGGREGATE BASE COURSE

#### **DEFINITION AND TYPES**

#### **DEFINITION**

ABC: A BASE COMPOSED OF AN APPROVED AGGREGATE MATERIAL HAULED TO THE ROAD, PLACED ON THE ROAD, COMPACTED, AND SHAPED TO THE LINES, GRADES, DEPTHS, AND TYPICAL SECTIONS SHOWN IN THE PLANS OR ESTABLISHED BY THE ENGINEER. (520-1)

# TYPES OF ABC (TWO TYPES)

TYPE A ABC: IS SAMPLED BY THE PRODUCER FROM THE PRODUCTION PILE IN 2000 TON LOTS.

(PRODUCTION PILE CAN HAVE MATERIAL SHIPPED OUT WHILE NEW MATERIAL IS ADDED)

TYPE B ABC: IS SAMPLED BY THE **PRODUCER** FROM AN "APPROVED" STOCKPILE, WHICH HAS SPECIFIC PERMISSIBLE DIMENSIONS IN TERMS OF LAYER THICKNESS, TONNAGE PER LAYER, ETC. (NO MATERIAL CAN BE HAULED FROM AN APPROVED STOCKPILE UNTIL THE PILE IS COMPLETED, TESTED, AND APPROVED BY THE STATE SOILS ENGINEER)



#### **TYPES OF ABC (continued)**

TYPE B ABC: PRODUCER
PULLS QC SAMPLES IN 2000 TON
LOTS

# HAULING AND PLACEMENT

PRIOR TO DELIVERY OF ANY AGGREGATE MATERIAL, THE INSPECTOR SHOULD REVIEW THE FOLLOWING:

- RELATED SECTIONS OF THE SPECIFICATIONS
- RELATED SECTIONS OF THE CONSTRUCTION MANUAL
- PLANS
- PROJECT SPECIAL PROVISIONS

#### **REMINDER:**

IMPROPER LOADING, PLACEMENT, OR MANIPULATING CAN TURN ACCEPTABLE MATERIAL INTO UNACCEPTABLE MATERIAL

#### PROPER PLACEMENT:

- PLACE MATERIAL AT OR NEAR OPTIMUM MOISTURE
- UTILIZE A MECHANICAL SPREADER BOX (AVOID TAILGATE DUMPING)
- AS A GENERAL RULE-ADD APPROXIMATELY 1/3 THICKNESS TO ACHIEVE THE DESIRED COMPACTED THICKNESS

- •THE REAR TRUCK TIRES SHOULD REMAIN IN CONTACT WITH THE SPREADER BOX AS ABC IS BEING DUMPED
- WHEN THE EQUIPMENT MOVES FORWARD THE TRUCKBED SHOULD BE RAISED AS THE THE LEVEL OF ABC IN THE MECHANICAL SPREADER BOX DROPS
- AVOID OVERFILLING THE MECHANICAL SPREADER BOX
- THE MECHANICAL SPREADER BOX SHOULD BE KEPT 1/3 FULL TO PREVENT SEGREGATION

#### **SAFETY ISSUE!**

ANY TIME A DUMP TRUCK IS RAISING THE BED TO DUMP MATERIAL BE AWARE OF NEARBY POWERLINES

ALWAYS BE AWARE OF ANY MOVING VEHICLES OR CONSTRUCTION EQUIPMENT

DO NOT EXCEED 35 MPH WITH HAULING EQUIPMENT TRAVELING OVER ANY PART OF THE BASE (520-5)

AS AGGREGATE MATERIAL IS DELIVERED, PROJECT PERSONNEL SHOULD COLLECT THE WEIGH TICKETS AND MAINTAIN PROPER RECORDS TO ENSURE...


- THE CONTRACTOR IS PAID FOR PRODUCTS DELIVERED AND...
- IF ANY AGGREGATE FAILS TO MEET SPECIFICATIONS IT CAN BE LOCATED

#### PROPER RECORD KEEPING...

THE METHOD OF PAYMENT FOR ABC MATERIAL IS BASED ON THE WEIGH TICKET THEREFORE TO ENSURE PROPER RECORD KEEPING, FOLLOW GUIDELINES IN THE "RECORD AND REPORTS" SECTION (page R-110) OF THE NCDOT CONSTRUCTION MANUAL

### ROADWAY ASSURANCE SAMPLING

## IMPORTANCE OF PROPER SAMPLING



#### **DEFINITION**

**SAMPLE:** IS A PORTION, PIECE, OR SEGMENT THAT IS <u>REPRESENTIVE</u>
OF A WHOLE

PENALTIES ARE APPLIED WHEN A SAMPLE FAILS TO MEET THE SPECIFICATION REQUIREMENTS WHICH CAN LEAD TO A REDUCTION IN PAY OR REJECTION OF THE ABC

THEREFORE SAMPLING ABC WITH
THE **PROPER PROCEDURES** CAN NOT
BE OVEREMPHASIZED

- BOTH TYPE A ABC AND TYPE B ABC ARE TESTED BEFORE THE MATERIAL LEAVES THE QUARRY BY THE PRODUCER AND THE NCDOT
- HOWEVER ROADWAY (RA) SAMPLES ARE OBTAINED TO ENSURE THE MATERIAL HAS MAINTAINED THE SAME QUALITY AS AT THE QUARRY

• WHEN SAMPLING FROM ROADWAY A NCDOT APPROVED SAMPLING RING MUST BE USED

• THE SAMPLING RING ISOLATES
THE SAMPLE FROM THE REST THE
OF ROADWAY

• EACH TEST WILL REQUIRE A RA SAMPLE PAIR "A" AND "B"

BOTH "A" AND "B" MUST WEIGH
70 POUNDS DRY TO BE PROCESSED

- Samples for gradation need to be obtained on the roadway (520-6), by a certified ABC sampling technician, behind the placing operation, prior to compaction, using random numbers for the width and tonnage.
- Care should be taken not to contaminate ABC sample with subgrade material when collecting sample from the roadway using NCDOT sampling ring.

#### **EQUIPMENT:**

- 1. STEEL SAMPLING RING (12-INCH DIA., 9-INCH DEEP)
- 2. SCOOP/LARGE SPOON
- 3. SMALL PICK
- 4. SAMPLE BAGS (GOOD CONDITION)
  AND SAMPLE CARDS
- 5. WOODEN MALLET

#### **PROCEDURE:**


- 1. PLACE SAMPLE RING ON FLAT SURFACE OF MATERIAL TO BE TESTED
- 2. USE PICK TO CAREFULLY LOOSEN MATERIAL WITHIN THE RING AND REMOVE WITH SCOOP OR LARGE SPOON AND PLACE IN SAMPLE BAG
- 3. LOWER THE RING AS MATERIAL IS REMOVED BY TWISTING OR LIGHTLY TAPPING THE RING WITH

- 3. A WOODEN MALLET. REMOVE ALL THE MATERIAL DOWN TO THE FULL DEPTH OF THE LAYER
- 4. IF TWO FULL BAGS HAVE BEEN
  OBTAINED AFTER THE RING
  REACHES THE BOTTOM OF THE
  LAYER, GO TO STEP 6. IF NOT MOVE
  THE RING OVER SUCH THAT THE
  NEW POSITION OF THE RING
  OVERLAPS THE PREVIOUS POSITION

#### Page 11

#### MOVING SAMPLING RING

#### FIRST BAG FULL



SECOND BAG FULL

TOP VIEW

- 5. REPEAT STEPS 2 TO 4
- 6. <u>COMPLETELY</u> FILL OUT A
  SAMPLE CARD FOR EACH BAG.
  PLACE CARD IN A CLEAR
  PLASTIC BAG AND THEN PLACE
  IN EACH SAMPLE BAG.

## SAMPLING FREQUENCY RA SAMPLING

#### TYPE A ABC OR TYPE B ABC


- PULL A SAMPLE PAIR EVERY 5000 TONS OR FRACTION THEREOF PLACED (1010-2)(C)
- THE "A" SAMPLE IS PULLED FROM THE FIRST 2500 TONS
- THE "B" SAMPLE IS PULLED FROM THE SECOND 2500 TONS

#### **NOT IN MANUAL**

- WHEN ABC IS PLACED IN TWO LAYERS, CLOSE OUT THE FIRST LAYER

   (I. E. obtain both A and B samples from one layer only)
- HAVE EACH LAYER OF MATERIAL SAMPLED, TESTED, COMPACTED, AND APPROVED PRIOR TO PLACING SUCCEEDING LAYER OF BASE MATERIAL OR PAVEMENT (520-5).

## RANDOM NUMBERS EXAMPLE PROBLEM



• USE RANDOM NUMBERS TO LOCATE SAMPLING SITES IN ORDER TO PREVENT BIASED SAMPLING (1010-2)(C)

#### **EXAMPLE 1**

## (ASSUME 12' LAYDOWN WIDTH) RANDOM NUMBERS ARE AS FOLLOWS:

1234 ← COLUMN NUMBERS

7316

3204

2976

8303

5 5 5 6

• LOT SIZE 5000 TONS

**5000 TONS** 

#### **EXAMPLE 1** (CONT)

• TAKE THE "A" SAMPLE FROM THE FIRST 2500 TONS AND THE "B" SAMPLE FROM THE SECOND 2500 TONS

2500 TONS "A"

2500 TONS "B"

### EXAMPLE 1 (CONT) Page 12 UTILIZE RANDOM NUMBERS (7316)

2500 TONS "A"

"A" SAMPLE TAKEN AT: 2500 TONS X 0.73 = 1825 TONS

12'  $\times$  0.16 = 2' FROM EDGE

PULL THE "A" SAMPLE

2500 TONS "B"

"B" SAMPLE TAKEN AT:

2500 TONS X 0.32 = 800 TONS

800 + 2500 = 3300 TONS

12' X 0.04 = .48' < 2' USE 2'

PULL "B" SAMPLE

# SAMPLING ABC STABILIZER AGGREGATE

#### STABILIZER AGGREGATE "S.A."

- UTILIZED TO STABILIZE SUBGRADE SOILS
- A TWO TO THREE INCH LAYER OF S.A. IS ADDED AND MECHANICALLY MIXED WITH THE SOIL (510-3)

#### SAMPLING STABILIZER AGGREGATE

• IN ORDER TO OBTAIN A REPRESENTATIVE SAMPLE, THE S.A. MUST BE SAMPLED FROM THE SPREADER BOX

- EACH TEST REQUIRES A "RA" SAMPLE PAIR "A" AND "B"
- EACH SAMPLE PAIR MUST WEIGH 70 LBS EACH TO BE PROCESSED

• SAMPLING LOT SIZE FOR S.A. IS 5000 TONS

• USE RANDOM NUMBERS TO DETERMINE SAMPLING SITE (PREVENT BIASED SAMPLING)

- WHEN THE TRUCK DUMPS THE MATERIAL IN THE SPREADER BOX, TYPICALLY A CONICALLY SHAPED PILE IS FORMED
- STRIKE OFF THE PILE TO CREATE A FLAT SURFACE FOR SETTING THE SAMPLING RING

• PLACE THE SAMPLING RING ON THE EXPOSED FLAT SURFACE AND SAMPLE ENOUGH MATERIAL TO FILL TWO BAGS OR A MINIMUM 70 LBS (AS DISCUSSED PREVIOUSLY)

#### **SAMPLING ABC**

## CEMENT TREATED BASE COURSE (C. T. B. C.)

C.T.B.C.

- CEMENT IS ADDED TO ABC
- PLANT-MIXED CTBC HAS THE CEMENT ADDED AT THE PLANT IN A PUGMILL (540-5)(B)
- ROAD-MIXED CTBC HAS THE CEMENT ADDED AFTER THE ABC IS PLACED ON THE ROADWAY (540-5)(C)

#### PLANT-MIXED CTBC

• CEMENT IS ADDED ALONG THE CONVEYOR BELT

• MUST SAMPLE BEFORE CEMENT IS ADDED

SAMPLING LOT SIZE IS 5000 TONS

- USE RANDOM NUMBERS TO DETERMINE THE TONNAGE TO PULL THE SAMPLE
- EACH TEST WILL REQUIRE AN "A" AND "B" SAMPLE (EACH SAMPLE MUST WEIGH 70 LBS EACH)

#### **EQUIPMENT:**

- 1. FLAT TIP SHOVEL
- 2. BRUSH
- 3. 5-GALLON BUCKET
- 4. SCOOP
- 5. SAMPLE BAGS
- 6. SAMPLE CARDS

#### **PROCEDURES:**

- 1. USE RANDOM NUMBERS TO DETERMINE TONNAGE TO PULL SAMPLE
- 2. STOP CONVEYOR BELT AT APPROPRIATE TONNAGE
- 3. USE FLAT-TIP SHOVEL TO ISOLATE APPROXIMATELY AN 18 TO 24 INCH SECTION

- 4. USING THE SCOOP, PLACE THE MATERIAL IN THE BUCKET
- 5. REMOVE ALL THE MATERIAL FROM THE ISOLATED SECTION INCLUDING THE FINES AND PLACE IN THE BUCKET
- 6. CAREFULLY TRANSFER THE
  MATERIAL TO THE SAMPLE BAGS
  AND PLACE COMPLETED CARDS IN
  EACH BAG

#### **ROAD-MIXED CTBC**

• SAMPLE THE ABC ON THE ROADWAY PRIOR TO ADDING THE CEMENT

• FOLLOW THE SAME PROCEDURES
AS THOSE USED FOR OBTAINING
ABC SAMPLES ON THE ROADWAY

## SAMPLE IDENTIFICATION AND NUMBERING

#### SAMPLE IDENTIFICATION AND Page 5 NUMBERING

- SAMPLES ARE GIVEN AN "RA"
  DESIGNATION FOLLOWED BY THE
  NUMBER AND AN "A" OR "B"
- NUMBERING WILL START WITH "1" AND RUN CONSECUTIVELY FOR THE ENTIRE PROJECT

#### FOR EXAMPLE:

THE FIRST SAMPLE PAIR TAKEN
ON THE PROJECT WILL BE LABELED
RA-1A (2 BAGS MINIMUM OF 70 LBS)
RA-1B (2 BAGS MINIMUM OF 70 LBS)

THE SECOND SAMPLE PAIR TAKEN
ON THE PROJECT WILL BE LABELED
RA-2A (2 BAGS MINIMUM OF 70 LBS)
RA-2B (2 BAGS MINIMUM OF 70 LBS)

#### PLACE EACH SAMPLE CARD IN A PLASTIC BAG TO PROTECT IT

PLACE A SAMPLE CARD IN EACH BAG

BOTH "A" AND "B" SAMPLES MUST BE TURNED IN AT THE SAME TIME

# FOR FILLING OUT A SAMPLE CARD FOLLOW THE EXAMPLE ON PAGE 6 IN MANUAL

#### FAILURE OF RA SAMPLE



#### FAILURE OF RA SAMPLE Type A ABC

- RESIDENT ENGINEER WILL REQUEST A CHECK SAMPLE FROM THE SOILS ENGINEER.
- THE SAMPLING LOT (5000 TONS)
  WILL BE DIVIDED INTO TWO 2500
  TON SUBLOTS AND A SAMPLE PAIR
  WILL BE OBTAINED FROM EACH
  SUBLOT

• THE GRADATION RESULTS OF EACH SAMPLE PAIR SHALL BE AVERAGED TO DETERMINE ACCEPTANCE OF EACH SUBLOT

• THE AVERAGES MUST FALL WITHIN COLUMN C OF TABLE 1010-1

 IF THE AVERAGES EXCEED ANY OF THE LIMITS ON COLUMN C, AND THE TEST RESULTS INDICATE THAT THE MATERIAL CAN BE CORRECTED, THE SECTION CAN BE CORRECTED WITH APPROVAL FROM THE AREA ROADWAY CONTRUCTION ENGINEER AND THE SOILS ENGINEER (AT NO COST TO THE DEPARTMENT)


- ONCE THE MATERIAL HAS BEEN CORRECTED, A SAMPLE PAIR IS TO BE OBTAINED FROM THE CORRECTED SUBLOT(S) (PROJECT PERSONNEL)
- THE AVERAGE GRADATION TEST RESULTS MUST FALL WITHIN COLUMN B OF TABLE 1010-1 TO BE CONSIDERED ACCEPTABLE (1010-2)(A)

 WHEN THE AVERAGE GRADATION TEST RESULTS FOR A SUBLOT EXCEED ANY OF THE LIMITS SHOWN IN TABLE 1010-1 COLUMN C, AND THE SUBLOT CAN NOT BE CORRECTED, OR IF THE CORRECTED SUBLOT EXCEEDS ANY OF THE LIMITS OF TABLE 1010-1 COLUMN B, THE SUBLOT WILL BE REJECTED AND SHALL BE REMOVED AND REPLACED AT NO COST TO THE DEPARTMENT (520-6)

• THE REPLACEMENT MATERIAL SHALL MEET THE SPECIFICATION REQUIREMENTS FOR TYPE A ABC

#### FAILURE OF RA SAMPLE TYPE B ABC

• FOLLOW SAME PROCEDURES
AS DISCUSSED ON THE PREVIOUS
SLIDE. STEPS ARE SUMMARIZED ON THE
FOLLOWING SLIDE



#### **CHECK SAMPLES**



#### **CHECK SAMPLES**

- THE CONTRACTOR MAY REQUEST THAT A CHECK SAMPLE BE TAKEN WHEN A TEST SAMPLE(S) FAILS TO MEET SPECIFICATIONS.
- THE CHECK SAMPLES MAY BE TAKEN BEFORE AND/OR AFTER CORRECTION.

#### Page 9

• THE CHECK SAMPLES ARE NAMED AS FOLLOWS: RA-1C, RA-1D, RA-1E, AND RA-1F, ETC.

### COMPACTION OF ABC


### ACHIEVING ADEQUATE COMPACTION FOR ABC OR CTBC BEGINS WITH...

- QUALITY AGGREGATE
- ADEQUATE FOUNDATION
- PROPER CONSTRUCTION EQUIPMENT
- PROPER CONSTRUCTION PRACTICES
- AN UNDERSTANDING OF LABORATORY METHODS FOR ESTABLISHING OPTIMUM MOISTURE AND MAXIMUM DRY DENSITY

## A MOISTURE DENSITY CURVE OR "UNIT WEIGHT" IS PERFORMED ON QUARRIES THAT ARE SUPPLYING ABC TO THE DEPARTMENT...

- MATERIALS INSPECTOR SUBMITS A 4-BAG SAMPLE FROM EACH QUARRY TO THE SOILS LABORATORY
- THE SOILS LABORATORY PERFORMS
  A MOISTURE DENSITY CURVE ON THE
  ABC USING AASHTO T-180 PROCEDURES
  AS MODIFIED BY THE DEPARTMENT

- THE MAXIMUM DRY DENSITY AND OPTIMUM MOISTURE ARE ESTABLISHED FOR EACH QUARRY ON THE APPROVED SOURCE LIST
- THE MAXIMUM DRY DENSITY IS USED AS THE TARGET DENSITY FOR PROJECT DENSITY CONTROL UNTIL THE NEXT UNIT WEIGHT IS PERFORMED,WHICH IS ABOUT EVERY 12 MONTHS



























Comments

#### NORTH CAROLINA DEPARTMENT OF TRANSPORTATION MATERIALS AND TESTS UNIT

0.114540

#### MOISTURE DENSITY DETERMINATION

**Project** 5.672 **Date** 7/1/2005

TIP No. MM CHARLOTTE Q41 Stone Content(%) 0.0 County Mecklenburg Bag Moisture (%) 0.0

Station SP Test Type AASHTO T-180


Sample No. 1-05 Submitted By R.HISSOM

Lab No. 724040 Tested By TDH

Mold Weight (g) 3980 Mold Volume(ft³)

8400

Test No.	Weight of Mold+Soil (g)	Weight of Wet Soil (g)	Wet Unit Weight (pcf)	Wt. Wet Sample (g)	Wt. Dry Sample (g)	Water Content %	Dry Unit Weight (pcf)
1	11951.0	7971.0	153.4	7971.0	7635.0	4.40	147.0
2	12181.0	8201.0	157.8	8201.0	7787.0	5.32	149.9
3	12232.0	8252.0	158.8	8252.0	7770.0	6.20	149.6
4	12256.0	8276.0	159.3	8276.0	7738.0	6.95	148.9
5							
6	1 1						



### THE FOLLOWING ITEMS CAN AID IN THE COMPACTION PROCESS

- TAKE THE NECESSARY STEPS TO ENSURE
  THE ABC IS AT OR NO MORE THEN 2 PERCENT
  ABOVE OPTIMUM MOISTURE FOR THE ENTIRE
  LAYER
- WHEN COMPACTING CTBC THE MATERIAL IS TO BE COMPACTED AT OR NO MORE THEN 1.5 PERCENT ABOVE OPTIMUM MOISTURE (540-6)

- WHEN THE COMPACTED DEPTH IS 8 TO 10 INCHES, A VIBRATORY SHEEPSFOOT CAN BE USED FOR A MAXIMUM OF 2 PASSES (540-6)
- A MOTORGRADER CAN EVEN THE SURFACE AND ADDITIONAL PASSES SHOULD BE MADE WITH THE VIBRATORY SMOOTH DRUM
- IF AVAILABLE, A PNEUMATIC ROLLER CAN FOLLOW THE VIBRATORY SMOOTH DRUM WITH THE FINAL PASSES MADE BY A SMOOTH DRUM ROLLER IN THE STATIC MODE TO FINISH THE SURFACE

• IF A NUCLEAR GAUGE IS AVAILABLE, DENSITY READINGS CAN BE TAKEN TO MONITOR THE COMPACTION OPERATION

• WHEN SETTING UP CTBC, COMPLETE FINAL COMPACTION WITHIN 3 HOURS AFTER THE WATER HAS BEEN ADDED TO THE MIXTURE (540-6)

#### **CONTACT INFORMATION:**

#### **Technical Trainers**

David Dunn ddunn@ncdot.gov

Johnny Gilliam cgilliam@ncdot.gov

Kevin Blalock kblalock@ncdot.gov

Scotty Jarman sjarman@ncdot.gov

JJ Myers jjmyers@ncdot.gov

#### **Technical Training Staff Map**



- David Dunn Div. 1, 2, 4, 5
- Kevin Blalock Div. 3, 6, 8
- Johnny Gilliam Div. 5, 7
- •Scotty Jarman Div. 9, 10, 12
- •J.J. Myers Div. 11, 13, 14

- (252) 792-1405
- (910) 893-6807
- (919) 329-4150
- (704) 289-1330
- (336) 679-8142